



For the connection of the tow bar connector box to the wiring of the vehicle.

ASSEMBLY

Clear the wiring to the left-hand and the right-hand rear lights in the luggage compartment. Find the wires having various functions with a test light and connect these to the wiring according to the diagram.

NB

The wires should not be cut and the insulation must not be removed. Place the wire in the continuous slot of the rapid-connector and the wire of the wiring set in the enclosed slot. Use pliers to cut the metal plate and close the lid.

Clamp	Function	Color
1	Left turn signal	Yellow
2	Rear fog light	Blue
3	Earth (Clamp 1 to 8)	White 1,5 mm ²
4	Right turn signal	Green
5	Right taillight	Brown
6	Brake light	Red
7	Left taillight	Black
8	Reverse light	Orange
9	Permanent power supply	Green 2,5 mm ²
10	Power supply caravan	Red 2,5 mm ²
11	Earth	White 1,5 mm ²
12	Reserve	
13	Earth (Clamp 9 to 12)	White 1,5 mm ²
2a	Rear fog light	Grey

If one wishes to use a connection in the connector box for a permanent power supply for the interior lighting of the caravan, the wire of minimum 2,5 mm² should be taken directly from the battery to clamp 9 of the connector box. Here however the floating fuse should be fitted.

